



CONNECTION GUIDE

Three Knob RGB LED Dimmer & Controller, 5-24V 8A/CH



CONTROLLER MODES			
1	Static Red	14	Blue Purple Fade
2	Static Green	15	Green Yellow Fade
3	Static Blue	16	Blue Cyan Fade
4	Static Yellow	17	Red Purple Fade
5	Static Purple	18	Blue White Fade
6	Static Cyan	19	Purple Cyan Yellow Fade
7	Static White	20	Red Green Blue Fade
8	RGB Fade In/Out	21	7 Color Fade
9	Red Green Fade	22	Red Green Blue Jump
10	Red Blue Fade	23	7 Color Jump
11	Green Blue Fade	24	White Strobe
12	Red Yellow Fade	25	7 Color Strobe
13	Green Cyan Fade		

- Power On/Off**
- Shuffle Between Modes**
- Speed Up Color Changing Modes**
- Slow Down Color Changing Modes**
- Increase Brightness**
- Decrease Brightness**
- Press and hold to save a color or scene**
- Press and hold to save a second color or scene**